



END DUMP SHUTTLE CART

Simply unload conveyor cart into Shuttle Cart, drive to field loader or pit. Use your tractor hydraulics to dump cart and open gate. Cart also makes its own hopper to keep material on field loader.

- **Heavy duty hoist lifts box with ease.**
- **Used with our field loader you will unload approximately 5,000 pounds per minute.**
- **And do it all from your tractor seat.**
- **Set box back down and head back to your pickup machine.**

MANUFACTURED BY:

JESSEE MACHINE WORKS

CHICO, CA 95926 PHONE: 530-342-4379